Sending email alerts with Node-RED



Revision: 20.09 Date: 2020-09-29



www.iqhome.org

Contents

Contents	2
1 Overview	3
2 Enable the Application Interface	4
3 Set up a Node-RED network to forward the sensor data	6

1 Overview

In this guide, you will learn how to send **email alerts** if a sensor's measurement exceeds a given threshold in your IQHome Sensor Network.

The pre-installed Node-RED service and IQHome package on your Gateway will be used to periodically collect and monitor your sensor data.

What you will need:

- IQ Home Gateway
- IQ Home Sensor
- Gmail Account



2 Enable the Application Interface

To collect sensor data with Node-RED, first, we need to enable the Application Interface feature on the gateway.

- 1. Connect to the Gateway using the "Link It!" Software
- 2. Go to the "Settings" tab
- 3. Enable "Application Interface" and set a "Port Send" value (e.g. 55000)

		Dashboard RF	Network Settings Web Viewer Files Terminal
Gateway Settings			
Main MQTT Subscribe	MQTT Settings		
Scheduler		Enable MQTT 📀	
WWAN		Hostname 📀	mqtt.iqhome.org
		Port 😧	8883
		Username 📀	v93zUZux672tevbW
		Password 📀	
		Client ID source select 🥹	Auto 🗸
		Client ID 💡	Serial number
	MQTT TLS Settings		
		Enable MQTT TLS 🥹	-
		TLS type 🥹	CA signed server certificates
		CA path 😮	/etc/ssl/certs
		Verify hostname 🥑	-
	Scheduler		
		Enable Scheduler 🥝	-
	Application Interface		
		Enable 🥹	
		Port listen 🥑	55001
		Port send 🥹	55000
	SensNet Interface		
	TCP Proxy		

The **Port Send** value selected here will be used in Node-RED.

Then enable the Node-RED scheduler for the sensors.

- 1. Open the "**RF Network**" tab
- 2. Switch to "Sensor Data"
- 3. Click on the clock icon in the top right corner labeled "Create Scheduler"
- 4. Enable the "Node-RED" Response option

Scheduler Settings		
Measured values	Temperature, Relative Humidity, CO2	
Energy efficient mode		
Active days	🗹 Mon 🗹 Tue 🗹 Wed 🗹 Thu 🗹 Fri 🗌 Sat 🗌 Sun	
Active hours	• •	9:00 - 16:59
Interval in active hours	•	10 min
Interval in inactive hours	•	60min
Response	🗌 Modbus 🗹 Node-RED 🔲 SensNet 🗌 MQTT	

You can also set the time intervals between the sensor measurements.

3 Set up a Node-RED network to forward the sensor data

For this demo, we will be using a **Temperature Sensor** [SI-T-02/SC] and a **Temperature and Relative Humidity Sensor** [SN-TH-02].

1. Switch to the Node-RED tab in LinkIt!

The **IQHome** nodes can be found in the bottom of the panel on the left side of your screen.



2. Add an iqhome **gateway** node. If you changed the used port in the first step, you can set it here by double-clicking on the node



 Add the sensor nodes corresponding to the sensors you are using in your IQHome network. In this example, we are using the SI-T-02/SC and SN-TH-02 sensors, so we will add the SI-T and SN-TH nodes



4. Set the device addresses corresponding to your sensor's addresses as seen in the LinkIt! RF Network tab by double-clicking the sensor nodes. We are using the default topic names generated by the sensor nodes, so you can leave the boxes under "Topics" empty. This topic will be the topic of the email notification.

Note

You can easily identify your sensors and their device addresses by using the "indicate" button in the right-click menu of the sensors under the **RF Network** tab in **LinkIt!** and finding the blinking LED on the sensor.



Each sensor node has outputs depending on what types of measurements can that sensor make.



5. In this demo, we will set thresholds for the **temperature** values of our sensors, so we add two **Switch** nodes to the temperature outputs of the sensor nodes. If the **temperature** measurement of either sensor crosses the threshold, Node-RED will send an email alert.



6. Open the configuration panel of the switch nodes by double-clicking on them. The measured values arrive in msg.payload as a simple value, so it's very easy to set up conditions for the incoming data. Let's set a threshold of 10 °C for both sensors by selecting the ">" operator and a number as an argument.

Properties		
Name 🗣	Name	
- Property	👻 msg. payload	
≡ >	✓ ⁰ ₉ 10	→ 1 💌

7. You can customize your email alert message by adding a **template** node. "**{{payload}}**" will be replaced with the measured value sent by the sensor.

	Delete	Cancel Done
[2] SLT ewitch	© Properties	
	Name Name	<i></i>
[3] SN-TH Switch	••• Property - msg. payload	
		Syntax Highlight: mustache 🗸 🗸
	1 A temperature sensor 2 The current temperat	has exceeded the threshod! ure is {{payload}} °C.

- [2] SI-T (switch [3] SN-TH (switch (swi
- 8. Add an email node connected to the output of the template node

9. Configure the **email** node. If you are using Gmail, you can leave the default settings in the Server and Port fields. Fill in the email address you would like to send the alerts to in the "To" field, and your **Google** username and password in the "Userid" and "Password" fields.

Properties	*
To To	alerts@iqhome.org
Server	smtp.gmail.com
>⊄ Port	465
🌡 Userid	iqhome
Password	••••••
● Use TLS?	
Name	Name

Note

If you have two-factor authentication enabled on your Google Account, you have to use an "App Password". You can find more information here: <u>Google Application Passwords</u>

10. **Deploy** your Node-RED network by clicking the **Deploy** button in the top right corner of your window



If you turn on your IQHome gateway and sensors, and a temperature measurement exceeds the given threshold (10 °C), you will get an email like the following:

to me			
A temp	erature ser	nsor has e	exceeded
The cu	rrent tempe	erature is	47.5 °C.

The topic of the email will be the topic set in the **Sensor nodes**. If you would like to customize the topic of the emails, you can set a custom topic there.

Properties	•	Ĩ
Name Name	Name	
Address	1	
Topics		
	(+ · · · · · · · · · · · · · · · · · · ·	